

ABB i-bus® KNX Energy Actuator SE/S 3.16.1 Product Information



Power and productivity for a better world™

ABB i-bus[®] KNX Energy Actuator SE/S 3.16.1

The new ABB i-bus[®] KNX Energy Actuator SE/S 3.16.1 is a Switch Actuator that records the energy consumption of the connected electrical loads in the building.

With the intelligent power grids of tomorrow – the Smart Grids – the electrical building installations will be facing new challenges. In order to increase the energy efficiency of buildings and at the same time integrate the consumers in the load compensation, it is necessary to switch electrical devices in buildings on and off based on external signals such as time, consumption thresholds or similar.

The ABB i-bus[®] KNX provides the optimum prerequisites for intelligent buildings.

The new Energy Actuator determines the active energy consumption per switching output. Furthermore, it provides the total consumption of all three outputs. All meter values can be sent cyclically, on request or when a start or stop event has occurred such as a time, operating period or when a defined consumption threshold is reached. Additionally, when a stop event occurs, the assigned output can be switched off.

For each channel, the active power, current and voltage as well as further electrical variables (apparent power, crest factor, power factor and frequency) can be measured. The measured values are made available via the KNX. They can be monitored with threshold values. Should an overshoot or undershoot of a defined threshold occur, a warning can be sent or a channel switched.

The ETS application also enables a simple load management functionality, where up to ten Energy Actuators can be interconnected. The electrical loads connected to the three floating switch outputs can be switched via the KNX or switched manually directly on the device.



Application

Active consumption measurement Monitoring of electrical values Load management through load control Switch Actuator, 3-fold


Benefits

Detection and representation of energy consumption in buildings Enhancement of the energy efficiency Intelligent control of the loads in the end circuit

Product

Energy Actuator SE/S 3.16.1

The Individual Functions: Active Consumption Measurement




Overview

Meters and intermediate meters

A meter (meter outputs A...C) successively measures the active energy consumption for every switching output. The total consumption for the device is determined by addition of all three channel meter readings and is also made available (Meter readings total).

The special feature in the Energy Actuator:

Every meter is assigned with an intermediate meter that can be programmed for individual measurement tasks. Each of the four intermediate meters can be started, stopped and reset via the KNX. The meter values can be sent cyclically, on request or when a start or stop event occurs.



The Individual Functions: Instruments and Power Values

The following values can be monitored by threshold values with the Energy Actuator:

Instrument values

- Current (per output)
- Voltage (per output)
- Frequency

Power values

- Active power (per output)
- Active power total (sum of outputs A...C)

Visualization example


| Microcontroller active | |
|------------------------|----------|
| Active power total | 88 W |
| Frequency | 50.04 Hz |
| A: Current | 0.14 A |
| A: Voltage | 227 V |
| A: Apparent power | 32 W |
| A: Power factor | 093 |
| A: Crest factor | 151 |
| A: Active power | 30 W |

Two thresholds are available for each of these values. Warnings can be sent, or a switch reaction can be parameterized, dependent on whether thresholds are exceeded or the value falls below the threshold.

Other values (without threshold monitoring)

- Apparent power
- Crest factor (current)
- Power factor


These values can be transferred or read via the KNX bus.



Benefits: Monitoring and signalling of equipment malfunctions Detection of voltage failures and frequency fluctuations Evaluation of the load Threshold value dependent switching

The Individual Functions: Load Control

With load control, an Energy Actuator can be parameterized as a master that can control up to ten further Energy Actuators as slaves. The master receives power values from the slaves that are added internally to the total power (sum of power values). If the total power exceeds a parameterized load limit, the master sends up to eight load shedding stages on the bus. The load limit can be modified via the bus, e.g. in dependence on the time or the currently active power tariff. On the slave devices, every output can be assigned with its own shedding stage. When the slave receives the shedding stage, it then switches all outputs off with the respective shedding stage. Should the total power still exceed the load limit after shedding a load stage, the master will send the next load shedding stage until the total load is again below the permitted load limit. After the programmable waiting time, the master will attempt to reconnect the shedding stages in reverse sequence.



Visualization example

| Load control active | | |
|--------------------------|--------|--|
| Load limit | 3000 W | |
| Load limit exceeded | NO | |
| Send load shedding stage | 1 | |
| Sum of power values | 2650 W | |
| (master and slaves) | | |

Benefits:

Limitation of the total power of up to 10 devices (30 channels)

Assigning priorities to the individual channels so that most important consumers can remain "on line" if the allowed load limit is exceeded.

Note:

In addition to the described functions, the renowned software functions of the ABB i-bus® KNX Switch Actuators (time, scene, safety, logic, forced operation) can be used with the Energy Actuator.

Technical Data

| | BÜRO BÜRO | BÜRO BÜRO E |
|--|---|---|
| | FLUK VERE _H | |
| BÜRD | | |
| Active consumption/ | Measuring range | 5.7 W 4,600 W (U _n = 230 V) |
| active power ¹⁾ | A a a una a u (0 E | 2.8 W 2,300 W (U _n = 115 V) |
| | | |
| | Accuracy (25500 mA) | ±6% of measured value |
| | Accuracy (500 mA 5 A) | ±3% of measured value |
| | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) | ±3% of measured value ±2% of measured value |
| Quere et il | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current | ±3% of measured value ±2% of measured value 25 mA |
| Current ¹⁾ | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A |
| | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) Accuracy (0.025 20 A) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA |
| Current ¹⁾ Voltage ¹⁾ | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) Accuracy (0.025 20 A) Measuring range (AC) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V |
| Voltage ¹⁾ | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) Accuracy (0.025 20 A) Measuring range (AC) Accuracy (95 265 V) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value |
| | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) Accuracy (0.025 20 A) Measuring range (AC) Accuracy (95 265 V) Measuring range | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz |
| Voltage ¹⁾ | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) Accuracy (0.025 20 A) Measuring range (AC) Accuracy (95 265 V) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value |
| Voltage ¹⁾ Frequency ¹⁾ | Accuracy (500 mA 5 A) Accuracy (5 A 20 A) Starting current Measuring range (AC) Accuracy (0.025 20 A) Measuring range (AC) Accuracy (95 265 V) Measuring range Accuracy (45 65 Hz) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value |
| Voltage ¹⁾ Frequency ¹⁾ Output | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos $\varphi = 0.45$) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value |
| Voltage ¹⁾ Frequency ¹⁾ | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos φ = 0.45)to EN 60 947-4-1 | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value 16 A/230 V AC |
| Voltage ¹⁾ Frequency ¹⁾ Output | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos $\varphi = 0.45$)to EN 60 947-4-1AC1 operation (cos $\varphi = 0.8$) | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value 16 A/230 V AC |
| Voltage ¹⁾ Frequency ¹⁾ Output | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos φ = 0.45)to EN 60 947-4-1 | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value 16 A/230 V AC |
| Voltage ¹⁾ Frequency ¹⁾ Output | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos $\varphi = 0.45$)to EN 60 947-4-1AC1 operation (cos $\varphi = 0.8$)to EN 60 947-4-1 | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value 16 A/230 V AC 16 A/20 A/230 V AC |
| Voltage ¹⁾ Frequency ¹⁾ Output | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos $\varphi = 0.45$)to EN 60 947-4-1AC1 operation (cos $\varphi = 0.8$)to EN 60 947-4-1C-load switching capacityFluorescent lighting load | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 ∨ ± 1 % of actual value 45 65 Hz ± 1 % of actual value 16 A/230 ∨ AC 16 A/20 A/230 ∨ AC 20 A |
| Voltage ¹⁾ Frequency ¹⁾ Output | Accuracy (500 mA 5 A)Accuracy (5 A 20 A)Starting currentMeasuring range (AC)Accuracy (0.025 20 A)Measuring range (AC)Accuracy (95 265 V)Measuring rangeAccuracy (45 65 Hz)AC3 operation (cos $\varphi = 0.45$)to EN 60 947-4-1AC1 operation (cos $\varphi = 0.8$)to EN 60 947-4-1C-load switching capacityFluorescent lighting loadto EN 60 669-1 | ± 3 % of measured value ± 2 % of measured value 25 mA 0.025 20 A ± 1 % of actual value and ± 10 mA 95 265 V ± 1 % of actual value 45 65 Hz ± 1 % of actual value 16 A/230 V AC 16 A/20 A/230 V AC 20 A 16 A/20 AX/250 V AC (200 μF) |


¹⁾ The specified values only apply where there is no DC component. A DC component distorts the measured result.

Application Examples

The intermediate meter is started when a usage period commences by a bus telegram. The energy consumption of the connected devices is recorded during the usage period. The intermediate counter sends the meter reading and is reset, after a stop telegram is received. This function can be applied to record and represent the energy consumption of IT workstations. Outside the usage period, the supply of energy to the IT devices can be switched off using the switching functionality of the Energy Actuator in order to avoid standby power consumption.

Application example 1


Distributed consumption recording during the usage period



The intermediate meters of the individual energy actuators are synchronized once a day by a bus telegram. The meter reading is sent cyclically on the bus. Energy consumption curves can be represented in this way for all loads. This function can be applied for the comparison of energy consumption in lighting or air-conditioning of manufacturing or storage facilities at freely definable intervals (week, month, year).

Application example 2

Representation of the energy consumption curve on the load level



Contact

ABB STOTZ-KONTAKT GmbH

Eppelheimer Straße 82 69123 Heidelberg, Germany Phone: +49 (0)6221 701 607 Fax: +49 (0)6221 701 724 e-mail: knx.marketing@de.abb.com

Further Information and Local Contacts: www.abb.com/knx

Note:

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail.

ABB AG does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents - in whole or in parts - is forbidden without prior written consent of ABB AG.

Copyright© 2010 ABB All rights reserved

